

Using the Bluetooth

On some phones, the UFED enables you to use Bluetooth instead of data cables for the extraction process. When you choose Bluetooth for the connectivity type, follow these instructions:

1. Phone Settings


On the mobile phone, you must enable the phone to connect via Bluetooth, by turning Bluetooth capabilities on.

In addition, you must set the Bluetooth services to 'Visible' on the phone.

2. UFED Bluetooth Adapter

The UFED kit comes with a Bluetooth USB adapter, as shown below.






Insert the Bluetooth adapter in either of the two USB ports at the top of the UFED, as shown below. Press  to continue.



3. Identifying the Phone via Bluetooth

The UFED searches for visible Bluetooth devices within its proximity, and provides a list of all devices that it finds. Select the appropriate device from this list.

Use the   keys to move between options.

Press  to continue. The UFED then instructs you to enter "0000" in the phone to complete the pairing between the devices. Once doing this, all data transfer between the UFED and the phone will be performed using Bluetooth.